


# **Tension Roller Joint Replacement**

Program 0380

#### **Order-Number**

03-R004-0149



## Contents

l	Requir	ed Tools	2
2	Seque	Sequency of Assembly Works	
	2.1	Remove Toothed Belt	2
	2.2	Optional: Remove Tension Roller	2
	2.3	Unscrew Screws M8x25	3
	2.4	Dismantle Bushing and Threaded Rod	4
	2.5	Clean Bearing Section of Threaded Rod	4
	2.6	Assemble new Bushing with Bearing Plain Bearing Bushing	5
	2.7	Attach Threaded Rod and Bushing	5
	2.8	Insert Screws M8x25 and tighten	6
	2.9	Check Function of Joint	6
	2.10	Reattach to motorized Cable Trolley	6
	2.11	Check Function	7



# **Tension Roller Joint Replacement**

Program 0380

# 1 Required Tools

- Wrench SW13
- Wrench SW36
- LOCTITE® 243
- Trummeter

# 2 Sequency of Assembly Works

#### 2.1 Remove Toothed Belt

Loosen belt tension and remove belt according to MAL0300-0006-EN

#### 2.2 Optional: Remove Tension Roller


It might be advisable to remove the whole tension roller from the motorized cable trolley for easier handling.



# Tension Roller Joint Replacement

Program 0380


#### 2.3 Unscrew Screws M8x25





# **Tension Roller Joint Replacement**Program 0380


#### 2.4 Dismantle Bushing and Threaded Rod



The roller itself has been hidden in the picture for better visibility. It is not necessary to disassemble the roller.

- 1. Slide bushing and threaded rod to wider section of keyhole
- 2. Pull out threaded rod (both parts are free now)

#### 2.5 Clean Bearing Section of Threaded Rod




- Remove dirt
- Remove surface rust




# **Tension Roller Joint Replacement**

Program 0380

## 2.6 Assemble new Bushing with Bearing Plain Bearing Bushing



## 2.7 Attach Threaded Rod and Bushing




- 1. Insert tip of threaded rod into bracket
- 2. Slide threaded rod and bushing to narrow section of keyhole



# **Tension Roller Joint Replacement**

Program 0380

#### 2.8 Insert Screws M8x25 and tighten



- Secure with LOCTITE® 243
- Tighten to 21,4 Nm

#### 2.9 Check Function of Joint

Check if the newly assembled joint can be rotated smoothly.

#### 2.10 Reattach to motorized Cable Trolley

Follow the instructions in MAL0300-0006-EN to

- reattach the tension roller,
- install new belt,
- tension belt and
- check belt tension.



# **Tension Roller Joint Replacement**

Program 0380

#### 2.11 Check Function

- Tilt tension roller
- Move motorized cable trolley by hand

The tension must align itself as soon as the belt moves!

Conductix-Wampfler GmbH

Rheinstraße 27 + 33 79576 Weil am Rhein - Märkt Germany

UK

Importer for the United Kingdom: Conductix-Wampfler Ltd.

1, Michigan Avenue Salford M50 2GY United Kingdom Phone: +49 (0) 7621 662-0 Fax: +49 (0) 7621 662-144 info.de@conductix.com www.conductix.com

Phone: +44 161 8480161 Fax: +44 161 8737017 info.uk@conductix.com www.conductix.com