


Installation Instructions


Replacement Kit Cellular Buffer Ø100x150 Program 0365



Order-Number

03-P025-0248

03-P025-0249






1 Matching Table

The following table shows replacement kits and the matching cable trolleys, which have been approved by design department.

Replacement Kit	Matching Cable Trolleys
03-P025-0248	all standard cable trolleys with Ø112 and Ø125 main rollers acc. to catalogue KAT0365-0001
03-P025-0249	special trolleys with Ø160 main rollers

2 Required Tools

	Hexagon socket wrench SW6 (A = 6 mm)
	Wrench SW17 (B = 17 mm)
	Torque wrench SW17 (B = 17 mm)

3 Sequence of Assembly Works




Injury hazard due to falling objects!


Block off danger zone below mounting area while mounting.

All old cellular buffers Ø80x80 within the festoon system have to be replaced by the replacement kit. There may be exceptions especially near the end clamp and/or towing clamp/trolley. Please refer to additional information given by Conductix-Wampfler e.g. the updated drawing of the festoon system.


1. Untighten and remove screws from old cellular buffers.




2. Remove old cellular buffers.



3. Position buffer plate 03-B020-8844 to the cable trolley (orientate towards **landside** if no other information is given).




4. Add countersunk screws 7991-M10X035-A2-70.




Installation Instructions


Replacement Kit Cellular Buffer Ø100x150 Program 0365



5. Install washers 0125-A10,5-A4 and self-locking nuts 0985-M10-A4 and tighten the nuts with 20 Nm.




6. Position angled buffer plate 03-B020-... and cellular buffer 03-P022-0005 (orientate towards waterside if no other information is given).




Installation Instructions

Replacement Kit Cellular Buffer Ø100x150 Program 0365




7. Install Tuflok® hexagon screws 0933-M10X035-A4-TUFLOK and washers 0125-A10,5-A4 and tighten them with 44 Nm.




WARNING!

Injury hazard due to falling objects!
Only use screws with Tuflok® thread locker!



Installation Instructions

Replacement Kit Cellular Buffer Ø100x150 Program 0365



Conductix-Wampfler GmbH
Rheinstraße 27 + 33
79576 Weil am Rhein - Markt
Germany

Phone: +49 (0) 7621 662-0
Fax: +49 (0) 7621 662-144
info.de@conductix.com
www.conductix.com



Importer for the United Kingdom:
Conductix-Wampfler Ltd.
1, Michigan Avenue
Salford
M50 2GY
United Kingdom

Phone: +44 161 8480161
Fax: +44 161 8737017
info.uk@conductix.com
www.conductix.com