

Motorized Cable Trolley Replacement of Tension pulley Program 0380

Order-Number

03-L072-...



Contents

1	Require	ed Tools	2
2	Working Steps		2
	2.1	Disassembly Steps	3
	2.2	Assembly Steps	4



Motorized Cable Trolley Replacement of Tension pulley Program 0380

1 Required Tools



2 Working Steps



Risk of injury!

- \rightarrow Secure the motorized festoon system from unexpected switch-on
- → Safety devices that have removed must be immediately remounted and inspected after work has been completed
- → Any used measuring tools must be cleaned up/collected after completion and their inventory must be checked
- \rightarrow Before approaching systems with damping devices, they must first be released



Motorized Cable Trolley Replacement of Tension pulley Program 0380

2.1 Disassembly Steps

1. Dismount protective cover. Loosen the 6 screws (1), 3 turns and dismount the cover (2).

 Dismount toothed belt (1). Untighten nuts (2 and 3) to retract tension pulley. Remove toothed belt (1) without applying force to it.

 Check whether the joint of the tension pulley can be turned without significant force.
If so, exchange only the roller itself. If the joint does not function properly, exchange the entire tension



pulley.

Installation Instructions



Motorized Cable Trolley Replacement of Tension pulley Program 0380

Exchanging the entire tension pulley

4. Remove nut (2) to extract tension pulley.



Exchanging the roller

4. Remove the nut and washer (5) and pull out the screw (6). Now the old roller body (4) can be removed



2.2 Assembly Steps

The assembly is made in reverse order. Use new fastening elements.

- 1. Insert the new tensioning pulley with threaded rod, secure it against falling out with the nut (2).
- Replace the new roller body (4) and push the screw (6) through the hole. Then fix the bolt again with the nut (5) (Tightening torque: 44 Nm).





Installation Instructions



Motorized Cable Trolley Replacement of Tension pulley Program 0380



 \rightarrow After 6.000 crane operating hours both toothed belts must be replaced. Assembly works at the toothed belt drive must comply with the particularities of the belt design. The operating behavior, utilization and the lifetime are dependent on the quality of the producer's recommendations.

 \rightarrow In case of worn out or defective toothed belt, always replace both toothed belts.

2. Mount toothed belt.

Put on toothed belt (1) without applying force to it. Tighten nut (3) to extend tension pulley. Check and adjust toothed belt (1) tightening (for details see Mounting Instructions). Secure belt tensioner by tightening nut (2)



3. Mount protective cover.

Conductix-Wampfler GmbH Rheinstraße 27 + 33 79576 Weil am Rhein - Märkt

79576 Weil am Rhein - Märkt Germany

> Importer for the United Kingdom: Conductix-Wampfler Ltd.

UK CA Conductix-wampfier Ltd. 1, Michigan Avenue Salford M50 2GY United Kingdom Phone: +49 (0) 7621 662-0 Fax: +49 (0) 7621 662-144 info.de@conductix.com www.conductix.com

Phone: +44 161 8480161 Fax: +44 161 8737017 info.uk@conductix.com www.conductix.com