

## Drive roller

Program 0380

Crane:	Location:	
Name:	Date:	
Signature:		



The checklist is addressed to qualified specialists who install and commission motorized festoon systems and who are familiar with the regulations regarding work safety and prevention of accidents.

All rollers have to be checked over the entire circumference!

	Motorized cable trolley			1	-			2	-			3	
	Roller	TL	EL	TR	ER	TL	EL	TR	ER	TL	EL	TR	ER
1	visible thickness of bandage (B) is correct												
2	no visible damages on bandage												
3	no gap between bandage and polyamide roller body												
4	no visible damage on polyamide roller body												
5	no visible damage on hub												
6	no gap between hub and shaft shoulder												
	Other abnormalities												

T = towing side; E = end clamp side; R = right side\*; L = left side\*

\* direction of view: towards towing side



## Drive roller

Program 0380

